EG SCH50 CHARGING STAND FOR SWITCH™ 2

USER MANUAL

WHAT'S IN THE BOX:

4 X CHARGING INDICATORS

2 X CHARGING SLOTS (LEFT)

2 X CHARGING SLOTS (RIGHT)

1 X CHARGING DOCK

1 X TYPE-C POWER INPUT

1 X MANUAL

1 X 80CM USB-A TO TYPE-C CHARGING CABLE

INSTALLATION & USE

1 Connect the charging dock to a power source using the included cable.

2 When the dock powers on, it will run a quick self-check:
- All 4 LED lights will turn red, then green.
  - You'll hear two beeps, and the dock will enter standby mode.

4 X LED LIGHTS WILL TURN RED, THEN GREN.

3 Insert your Joy-Con™ 2 controllers into the 4 charging slots. Make sure each one is properly connected.
Charging - the LED stays red and you'll hear a beep.
Fully charged - the LED turns green.

CHARGING - THE LED STAYS RED AND YOU'LL HEAR A BEEP.

* The product features a built-in magnetic function that automatically secures the handles when inserted into the charging slots.

SPECIFICATIONS

(Design and specifications are subject to change without notice.)

Type-C charging cable: 80cm
Input power rating: DC5V/1.5A
Output power rating: DC5V/200mA x 4
Operating temperature: -10℃ --- 40℃
Charging time: 3 ~ 4hours
Mass: Approx. 120g
Product dimensions: 96 × 65 × 138 mm